plcinfo@mooreplc.com | +86 18020776786

ABB MODEL-SPECIFIC PRODUCT

IMCPM01

IMCPM01 connects a CTT01 or CTT02 configuration and tuning terminal to an INFI 90 or Network 90 system. Verify the MMU position, front connector and fuse before planning replacement.

PRODUCT FAMILY	PRODUCT TYPE
INFI 90 / Network 90	**Configuration Port Module**

Exact model configuration

CONFIGURATION FIELD	DECODED VALUE
Displayed model	**IMCPM01**
Manufacturer	**ABB**
Product family	**INFI 90 / Network 90**
Product type	**Configuration Port Module**
Terminal connection	**CTT01 / CTT02**
Mounting	**One standard INFI 90 MMU slot**
Fuse rating	**0.5 A, 250 V**

Application fit

- Connect the documented CTT01 or CTT02 terminal to the installed MMU.
- Inspect the five-pin front connector, P1 connection and specified fuse.
- No jumper settings are specified; follow the manual installation checks.

PRODUCT-SPECIFIC REFERENCE	INSTALLATION NOTE
CTT01 / CTT02 One standard INFI 90 MMU slot 0.5 A, 250 V	The 85 mA at 5 VDC value belongs to CTT02 consumption, not an independent processor load. Preserve the specified fuse rating and confirm the installed terminal.

MODEL-SPECIFIC ENGINEERING REFERENCE

Before ordering IMCPM01

Use this page as a controlled procurement checklist. It does not replace the manufacturer datasheet, installation instructions or approval certificate.

Ordering limits and selected values

CONFIGURATION FIELD	DECODED VALUE
Manufacturer	**ABB**
Product family	**INFI 90 / Network 90**
Product type	**Configuration Port Module**
Terminal connection	**CTT01 / CTT02**
Mounting	**One standard INFI 90 MMU slot**
Fuse rating	**0.5 A, 250 V**

Procurement checklist

- Confirm the complete ordering code IMCPM01 and readable nameplate before shipment.
- Confirm the product family and product type against the installed item.
- Confirm recorded electrical ratings, interfaces, dimensions and configuration options.
- Confirm compatibility with the complete automation or power system.
- Confirm approval markings and certificate scope for the installation location.

DIRECT SALES INQUIRY

Send the full model **IMCPM01**, quantity, delivery country, and a clear nameplate or installation photo.

Sandy Lin | plcinfo@mooreplc.com | WhatsApp /Phone: +86 18020776786

Source and document status

Technical basis	User-supplied Bailey I-E96-216A legacy manual, hosted at infi90.com; not an ABB-controlled website.
Publisher	Moore Automation - independent industrial automation supplier.
Document status	Independent product manual; not a manufacturer-issued datasheet, conformity certificate or calibration certificate.
Important	Verify availability, revision status, compatibility, nameplate data and regulatory requirements before ordering.